

GASTEC

HOW TO READ YOUR GASTEC TUBES

For most GASTEC detector tubes, if the colour change layer exceeds or does not reach the calibration scale during measurements with standard sample volumes, the concentrations outside of the calibration scale can be measured by changing the sample volume accordingly.

